

# TsmWeb-STS Web Vending API

Copyright © 2013-2021 All Rights Reserved.

Document number PR-D2-1000

Revision 4.40

Authors Trevor Davel, Chris Adlington, Candice Moore

Date November 2021

Synopsis Describes the TsmWeb-STS Web Vending Service and API.

CONFIDENTIALITY: Use of this document is restricted to authorized members or staff of PRISM and to third parties who are authorised by PRISM in terms of written agreement/s entered into with PRISM.

DISCLAIMER: PRISM makes no representations or warranties whether expressed or implied by or with respect to anything in this document, and shall not be liable for any implied warranties of merchantability or fitness for a particular purpose or for any indirect, special or consequential damages.

# 1. Contents

1.	CONTENTS	2
2	INSTALLING & USING THE WEB SERVICE	3
	2.1 Installation.	3
	2.2 STARTING & STOPPING THE SERVICE	
	2.3 CONFIGURATION	
	2.4 Accessing web services	
	2.5 SECURITY PROCEDURES IN A PRODUCTION ENVIRONMENT	
	2.6 Troubleshooting	
	2.7 Upgrading the software	
	2.8 Uninstalling the software	
3.	APPLICATION PROGRAMMING INTERFACE (API)	5
	3.1 Overview	5
	3.2 TERMS, DEFINITIONS AND ABBREVIATIONS	
	3.3 ACCESS CONTROL AND AUTHENTICATION	
	3.4 Status codes	
	3.5 OUTPUT FORMATS (REPRESENTATIONS)	
	3.5.1 INI (default)	7
	3.5.2 TSV	
	3.5.3 XML	
	3.6 Debugging	
	3.7 TARIFF FILE FORMAT	
4	STSVEND API	.11
	4.1 API SERVICES	
	4.2 LEGACY API SERVICES	
	4.3 VEND CREDIT TOKEN	
	4.4 VEND METER-SPECIFIC ENGINEERING TOKEN	
	4.5 QUERY TRANSACTION COUNTER	
	4.6 CALCULATE WATT-HOURS (LEGACY)	
	INTEGRATION GUIDE	
	RECOMMENDED SERVICES	
	4.7 SPECIAL WARNINGS	
	4.8 Integration setup	
	4.9 ELECTRICITY CREDIT TOKEN, \$50, BLIND VEND	
	4.10 ELECTRICITY CREDIT TOKEN, \$100, MSNO VEND	
	4.11 Water Credit Token, \$70, Blind Vend	
	4.12 CURRENCY (ELECTRICITY) CREDIT TOKEN, \$120, BLIND VEND	
	4.13 CURRENCY (ELECTRICITY) CREDIT TOKEN, REPLAY PREVENTION	
	4.14 REPLAYED TRANSACTION IS REJECTED	
	4.15 CLEAR CREDIT MANAGEMENT TOKEN, MSNO VEND	
	4.16 QUERY METER INFORMATION	.28
5	AMENDMENT HISTODY	32

# 2. Installing & Using the Web Service

#### 2.1 Installation

Refer to PR-D2-0955 "TsmWeb-STS User Guide".

### 2.2 Starting & Stopping the service

The Prism TsmWeb service may be controlled via the Windows Service Control Panel.

There are various ways to access the Service Control Panel:

- Computer Manager → Services and Applications → Services
- Administrative Tools → Services
- Start → Run → services.msc

Refer to PR-D2-0955 "TsmWeb-STS User Guide".

# 2.3 Configuration

Refer to PR-D2-0955 "TsmWeb-STS User Guide".

# 2.4 Accessing web services

Use your web browser to access the URL <a href="http://localhost:80/">http://localhost:80/</a> to view the human-consumable services provided by the software.

- If you have changed the service configuration you may need to specify a different host or port in the URL.
- Services for automation, as documented in <u>3. Application Programming Interface</u>
   (<u>API</u>), cannot be accessed via a web browser. You must access them
   programmatically or using a <u>Debugging</u> tool (section <u>3.6</u>).

# 2.5 Security procedures in a production environment

Hardware Security Modules and cryptographic services should be operated with due regard to security procedures designed to protect keys and prevent misuse of the services.

- Security procedures are outside the scope of this document.
- Networks and network-accessible services should be secured against unintended access, for example by means of firewalls.

# 2.6 Troubleshooting

Problems starting the service:

- Check the System log in the Windows Event Viewer (accessible via Computer Manager or Administrative Tools) for messages from the Service Control Manager.
- Check the web service log: %INSTALL DIR%\tap.tcl.err

Problems accessing the service (networking & TCP/IP connectivity):

- Use the Service Control Panel or SC.EXE utility to check that the service is running.
- Check the web service logs for errors; the log will also indicate the TCP/IP address and port at which the service is listening.
- Check that your system is in fact listening for connections on the expected TCP/IP address and port by using the command netstat.exe -an
- Check the firewall settings in Control Panel → Windows Firewall.

• If the web service is running on another computer, use the ping.exe, telnet.exe and tracert.exe utilities to ensure that basic TCP/IP communication exists between the computers.

ping.exe and tracert.exe are built for network diagnostics but use the ICMP protocol and may be fooled by firewalls. If you can use telnet.exe to connect to the web server's address and port then the network and service are behaving correctly.

Problems accessing the Hardware Security Module (HSM) or performing cryptographic operations:

• Use the <u>StsClosedVending UI</u> to diagnose the problem.

Problems using the web services:

Refer to 3.6 Debugging.

# 2.7 Upgrading the software

Upgrades follow the same procedure as <u>Installation</u>. You must install an upgrade into the same folder as the original installation (the setup application will detect the correct folder).

# 2.8 Uninstalling the software

An Uninstall shortcut is provided in the Start menu under All Programs → Prism → TsmWeb. You can also uninstall the software via Control Panel → Add or Remove Programs.

■ Some files – such as configuration and logs – will not be removed by the uninstall application. You can manually remove them from the %INSTALL DIR% if required.

# 3. Application Programming Interface (API)

#### 3.1 Overview

Prism's web service APIs are designed to follow the REST<sup>1</sup> model:

- Where possible the services are stateless and resource oriented.
- Some services perform computations rather than resource manipulation and are exposed as REST-like remote procedure calls. Such services may only be accessed via the HTTP POST method.
- The HTTP GET, HEAD, PUT and DELETE methods are always idempotent (sideeffect free). POST is seldom (if ever) idempotent.
- Some services support queries<sup>2</sup> (parameters). The query string is appended to the URL for a GET request, or included in the request body for POST. The query string is built and encoded according to the HTTP specification.
  - XML, SOAP, or JSON encoded requests are not supported.
- The resource or output obtained from a service may be retrieved in different formats or *representations*. The client indicates the desired representation in the URL.
  - Web services meant for human consumption are generally only available in HTML format.
  - Web services meant for automation are generally available as INI, TSV or XMI
- The result of processing (success or failure) is indicated by HTTP Status Codes.
  - A 200 "OK" status indicates that the service executed successfully, and the body of the response will contain the requested resource or service output.
  - o All other codes have meanings as defined in the HTTP specification.

# 3.2 Terms, definitions and abbreviations

The table below describes the abbreviations used throughout this document.

BDT	BaseDate					
СС	CountryCode					
CRC CyclicRedundancyCode						
DAC	DeviceAuthenticationCode					
DOE DateOfExpiry						
DRN DecoderReferenceNumber (meter number						
DSN DecoderSerialNumber						
DUTK DecoderUniqueTransferKey						
EA EncryptionAlgorithm						
FAC	FirmwareAuthenticationCode					
IAIN IndividualAccountIdentificationNumber						

<sup>&</sup>lt;sup>1</sup> Representational State Transfer: <a href="http://en.wikipedia.org/wiki/Representational">http://en.wikipedia.org/wiki/Representational</a> State Transfer.

<sup>&</sup>lt;sup>2</sup> See <a href="http://en.wikipedia.org/wiki/Query string">http://en.wikipedia.org/wiki/Query string</a>.

ID	Identification; Identifier				
IIN	IssuerIdentificationNumber				
ISO	International Standards Organisation				
ISO	BIN Replaced by IIN				
KCT	KeyChangeToken				
KEK	KeyExchangeKey				
KEN	KeyExpiryNumber				
KLF	KeyLoadFile				
KRN	KeyRevisionNumber				
KT	КеуТуре				
LRC	LongitudinalRedundancyCheck				
Mfr	Manufacturer				
MPL	MaximumPowerLimit				
MPPUL	MaximumPhasePowerUnbalanceLimit				
PAN	PrimaryAccountNumber				
POS	PointOfSale				
RND	RandomNumber				
RO	Roll over				
SG	SupplyGroup				
SGC	SupplyGroupCode				
SHA	Secure Hash Algorithm				
STA	Standard Transfer Algorithm				
STS	Standard Transfer Specification				
STSA	Standard Transfer Specification Association				
TCDU	TokenCarrierDataUnit				
тст	TokenCarrierType				
TDEA	Triple Data Encryption Algorithm				
TI	TariffIndex				
TID	TokenIdentifier				
UC	UtilityCode				
VCDK	VendingCommonKey				
VDDK	VendingDefaultKey				
VK	VendingKey				
VUDK	VendingUniqueKey				

#### 3.3 Access control and authentication

The current generation web services are provided as an integration technology only – much like a DLL, COM object, or Prism's Conductor service – and do not provide access control or authentication mechanisms.

The services are meant to run on a secured network or on localhost (127.0.0.1), and should never be directly accessible to end-users.

#### 3.4 Status codes

The status codes that may be returned by a Prism web service are consistent with the HTTP specification<sup>3</sup>. The table below contains commonly encountered codes and information on the probably cause of the code.

In the case of client errors (codes 4xx) or server errors (codes 5xx) the response body will include more specific information on the cause or nature of the error.

Status Code	Meaning	Probable cause			
200	ОК	The operation completed successfully.			
302	Found  also known as  Moved Temporarily	The client should access the resource using a different URL (the correct URL will be in the Location: header).			
400	Bad Request	The resource or service was found, but the request is inappropriate. Common causes include:			
		<ul> <li>Missing or extra query parameters</li> </ul>			
		<ul> <li>Invalid or out-of-range parameter values</li> </ul>			
		<ul> <li>Trailing path information in the URL</li> </ul>			
404	Not Found	No document, resource or service was found at the requested URL.			
405	Method Not Allowed	The resource or service was found, but does not support the requested method of access (HTTP GET, POST, etc.)			
415	Unsupported Media	The requested representation is not recognised, or is not compatible with the resource or service.			
500	Internal Server Error	A runtime exception has occurred and the operation could not complete.			
501	Not Implemented	The requested service is not implemented in this version of the software.			
503	Service Unavailable	The requested resource or service is temporarily unavailable. This is usually caused by a dependency such as a database, network file system, or coprocessor being offline.			

# 3.5 Output formats (representations)

Web services meant for automation may produce their outputs in one of several representations. Most services support the following representations:

### 3.5.1 INI (default)

INI format consists of lines of key=value pairs, like a Windows INI file.

<sup>&</sup>lt;sup>3</sup> HTTP status codes: <a href="http://en.wikipedia.org/wiki/List">http://en.wikipedia.org/wiki/List</a> of HTTP status codes.

- The key is strictly alphanumeric.
- The value may contain any character that may be represented in the charset of the HTTP response except the line delimiter.
- The line delimiter is ASCII character LF = 10 (\n).

#### Example:

```
token=67701832116585202773
tokenHex=3AB8D399C40318455
txCredit=974
```

#### 3.5.2 TSV

Tab-Separated Value format is a list of alternating keys and values, delimited by the ASCII character TAB = 8 (\t).

- The keys are strictly alphanumeric.
- The values may contain any character that may be represented in the charset of the HTTP response except the TAB delimiter and the ASCII character LF = 10 (\n).
- A TSV response is contained within a single line; this format is thus not suitable for large responses.

Example (the TAB delimiter is indicated by  $\rightarrow$ )

```
token→21701356005869838267→tokenHex→12D2AB44F02295FBB→txCredit→973
```

#### 3.5.3 XML

The XML format is specified<sup>4</sup> by the W3C. Responses generated by Prism's web services use a subset of XML 1.0.

- No processing instructions, comments, or CDATA sections are used.
- Namespaces are not used, and elements (tag) may not have attributes.
- Empty tags are not used an empty value will have an open and close tag.
- No DTD or schema is used the meaning of the XML data is defined by the web service API specification.
- The entire response is contained with a <response> element.
- Each output field will be represented as an element within the <response>. The
  element name (tag) indicates the name of the output field. The content of the
  element is the value of the field.
- Encoding is not relevant to this API: all output values are represented as alphanumeric characters and will not require encoding to be included in an XML document.

#### Example:

# 3.6 Debugging

It is common to encounter problems during the development and integration of software components. In the Web Services environment these problems often relate to invalid data

<sup>&</sup>lt;sup>4</sup> Extensible Markup Language (XML): http://www.w3.org/XML/Core/.

encodings, caching, redirection or bad URLs. Such integration problems may be difficult to debug with a traditional IDE.

Prism has found the following tools, techniques and information sources to be helpful:

- Check the web service logs (see also <u>2.6 Troubleshooting</u>).
  - %INSTALL DIR%\tap.tcl.err
- For networking and TCP/IP connectivity problems, refer to <u>2.6 Troubleshooting</u>.
- For HSM and cryptographic subsystem problems, refer to 2.6 Troubleshooting.
- For web service testing and integration issues we recommend the cURL utility, an Open Source tool available from <a href="http://curl.haxx.se/">http://curl.haxx.se/</a>. curl runs on many platforms including Windows, Linux, Mac OS/X, Solaris and HP-UX.

 ${\tt curl}$  allows you to access web services from the command line, controlling the HTTP method and headers, URL, and request parameters. The full HTTP response including the resource code, headers and body can be displayed to give full visibility of the web service protocol.

#### 3.7 Tariff File Format

The tariff database can be updated by importing a tariff file. A tariff file is a text file containing records for each supply group code given a particular tariff index, subclass and active date. Each record consists of comma separated values where the first value of the record is a prefix describing the tariff record structure. Currently only "Tariff1" is supported by the system.

All fields are in ASCII for the length indicated. Representation is defined as follows:

a alphabetic

n numeric

an alpha-numeric

ah alpha-hex

ans alpha-numeric, special

#### Fields:

Prefix	an
Supply group code	n(6)
Tariff index	n(2)
Subclass	n(2)
Date active	n(10)
Tariff	n(1-*)

#### **Field Descriptions**

#### Prefix

The tariff record type for this entry. Currently only "Tariff1" is supported.

#### Supply group code

The supply group code the tariff applies to

#### Tariff index

The tariff index the tariff applies to for the given supply group. A tariff index less than 10 must be space padded with a zero

#### Subclass

The subclass the tariff applies to given the supply group and tariff index. E.g. water or electricity. Left padded with zero for a subclass less than 10

#### Date Active

The date from which this tariff value becomes active for that supply group.

#### Tariff

The tariff value in cents per 100Wh

#### Example:

```
# Comment line
Tariff1,123456,01,00,1382004571,50
Tariff1,123456,01,01,1330000000,90
Tariff1,888888,02,00,1382004571,30
```

# 4. StsVend API

The StsVend API provides services for STS token vending.

### 4.1 API services

- Vend Credit Token
- Vend Meter-Specific Engineering Token
- Query Transaction Counter

# 4.2 Legacy API services

Legacy API services are provided for compatibility with Prism's STSClosedVending product (v3.x). Do not use these services for new development.

Calculate Watt-Hours (LEGACY)

# 4.3 Vend Credit Token

Generates an IEC 62055-41 Class 0 "Credit Transfer Token" to transfer credit for any service type (determined by subclass) to a given meter.

URL	http://host/stsvend/VendCredit.format						
Formats	tsv (default), ini, xml						
HTTP method(s)	POST						
Input	meterId (required)						
Parameters (Required)	Identifies the meter that will consume the token.						
(rtoquirou)	Format: A printable ASCII string in any of the following formats:						
	For blind vending (to unregistered meters):						
	o 35 digit IDRecord (MeterPAN, DOE, TCT, EA, SGC, TI, KRN)						
	<ul> <li>Record2 (MagStripe) format with or without sentinels and LRC</li> </ul>						
	For vending to registered meters:						
	<ul> <li>11 digit DecoderReferenceNumber (DRN) (containing manufacturer code, device SN, Luhn/DRNCheckDigit)</li> </ul>						
	<ul> <li>16 digit PAN (as for 17 digit PAN but excludes first digit of the IIN)</li> </ul>						
	<ul> <li>17 digit PAN (as for 18 digit PAN but excludes trailing Luhn/PANCheckDigit)</li> </ul>						
	<ul> <li>18 digit PAN (IIN, country code, DSN, Luhn/PANCheckDigit)</li> </ul>						
	The Security Module in the vending server must have the Vending Key for the Supply Group Code on which the meter is registered.						
	subclass (required)						
	Gives the subclass of the STS Class 0 token, which determines the resource represented by the token (electricity, water, gas,).						
	Format: A decimal integer in the range -1 to 15.						
	If -1 is specified, the CDU will do a database lookup to determine the resource type of the meter that has been registered on the system.						
	The following values are accepted:						
	• -1 = Auto						
	0 = Electricity						
	• 1 = Water						
	• 2-15 = Reserved						
	value (required)						
	The desired currency value of the token, net of fees, expressed in "cents" (0.01 base currency units). To vend R50.01 you must supply value=5001.						
	This value will be converted into a number of resource units at the ruling Tariff (for the meter's installed location and configuration), then encoded into an STS TransferAmount per the STS standard. The encoding places an upper bound of 18,201,624 on the number of units.						
	Format: A floating point number (up to 3 digits precision); must be greater than or equal to 0 for subclasses 0-3.						
	v3.29.0: value is not net of fees, specification to be revisited.						

#### messageId (optional, default empty)

A unique transaction identifier.

MessageId may be used by clients to safely resubmit a transaction when the outcome of a previous attempted submission is unknown. Other uses of messageId include finding transactions for reprinting, reporting, diagnostics or fraud investigation.

A messageld is optional but strongly recommended. If omitted (or given as an empty string) then a unique messageld will be assigned by the server. Any other value must be unique per transaction; the transaction will be rejected as a duplicate if an identifier is reused.

We recommend that the messageId be constructed with the originating client or terminal ID as a prefix, and a transaction counter or timestamp as the suffix. You may want to include the username or the authenticated operator. We also recommend that the suffix has an ASCII sort order equivalent to the transaction order. For example we could use a POS identifier, an employee number, and an ISO 8601 point-in-time: "POS.23.4-emp0139-20130818T154022Z".

Format: A printable ASCII string string containing only alphanumeric characters or underscore '\_', hyphen '-', period '.' or comma ','; with a maximum length of 40 characters (equivalently: the value must match the Perl-Compatible regular expression '^[a-zA-Z0-9\_\-.]{0,40}\$').

#### vendType (optional, default 1)

Indicates whether the operation is a Trial vend (0) or a Prepayment vend (1).

Format: A decimal integer greater than 0.

#### Status codes

#### 200, 400, 402, 405, 415, 500, 503

#### Output

The output will include the following fields:

- **idRecord** 35 digit IDRecord per IEC 62055-41 (contains MeterPAN, DOE, TCT, EA, SGC, TI, KRN).
- subclass As for input.
- **description** A human-readable description of the token type.
- **vendTimeUnix** The date & time of the vend given as a Unix timestamp (seconds elapsed since the Epoch, 1970-01-01 00:00) expressed as a decimal integer.
- unitsActual The actual number of transfer units issued, as a floating point number. The scale/measure is given by unitName.
- **unitName** The name of the transfer unit for the subclass, as a printable ASCII string (e.g. "kWh", "kL").
- **valueActual** The monetary value of the credit represented by the token (net of fees), given in 0.01 base currency units, expressed as a floating point number (up to 3 decimal places precision).
  - This field typically equal to the input value, but may be slightly larger due to rounding (the STS standard requires all rounding to be in the customer's favour).
  - valueActual = tariff × unitsActual × 100
- **Tariff** The applicable tariff (base currency units per resource unit [given by **unitName**]), expressed as a floating point number.
- tokenDec The generated token as 20 decimal digits, suitable for

printing on a POS slip for entry into a meter via a keypad.

 tokenHex The generated token as 17 hexadecimal characters, suitable for transfer to a magnetic token carrier.

v3.29.0: valueActual and tariff changed from "decimal integer" to "floating point"

v4.23.8: unitsActual changed from "decimal integer" to "floating point".

#### Example of use #1 - XML response

#### Request

```
curl http://localhost:8080/stsvend/VendCredit.xml -d subclass=0 -d
meterId=60072700000000009===0207123456011 -d value=50
```

#### Response

```
<?xml version='1.0' encoding='utf-8'?>
<response><idRecord>6007270000000000000000000123456011</idRecord>
<tariff>11.0</tariff>
<subclass>0</subclass>
<description>Sale - Credit:Electricity</description>
<vendTimeUnix>1378384620</vendTimeUnix>
<unitsActual>0.5</unitsActual>
<unitName>kWh</unitName>
<unitName>kWh</unitName>
<table
```

#### Example of use #2 - INI response (with HTTP headers shown)

#### Request

```
curl -i http://localhost:8080/stsvend/VendCredit.ini -d subclass=0 -d
meterId=600727000000000009===0207123456011 -d value=100
```

#### Response

```
HTTP/1.1 200 OK
Date: Thu, 05 Sep 2013 12:38:06 GMT
Server: Prism WSHOST
set-cookie: nsssession=52287b2e.fK S9YptbHbIhUB8zz5jEQ; Path=/
content-length: 233
content-type: text/plain; charset=utf-8
cache-control: no-store, no-cache, must-revalidate, max-age=0, post-check=0, pre-
check=0
expires: Sun, 01 Jul 2005 00:00:00 GMT
pragma: no-cache
vary: Accept-Encoding
idRecord=60072700000000000900000207123456011
tariff=11.0
subclass=0
description=Sale - Credit:Electricity
vendTimeUnix=1378384860
unitsActual=1.0
unitName=kWh
valueActual=110
tokenHex=11111111111111111
tokenDec=2222222222222222222
```

# 4.4 Vend Meter-Specific Engineering Token

Generates an IEC 62055-41 Class 2 "Meter-specific Engineering Token" to issue a management instruction (determined by subclass) to a given meter.

URL	http://host/stsvend/VendMse.format					
Formats	tsv (default), ini, xml					
HTTP method(s)	POST					
Input	meterId (required) As for Vend Credit Token.					
Parameters (Required)	Subclas	ss (required)				
(rtoquilou)	Gives the subclass of the STS Class 2 token, which determines the management instruction represented by the token.					
	Sub class	Management function	Supp range			
	0	SetMaximumPowerLimit	0 to 18,201,624			
	1	ClearCredit	0 to 65535			
	5	ClearTamperCondition	0			
	6	SetMaximumPhasePowerUnbalanceLimit	0 to 18,201,624			
	7	SetWaterMeterFactor	0 to 65535			
	Format: A decimal integer in the range 0 to 15 (excluding 3 or 4, which are reserved for Key Change).					
	Supp (c	Supp (optional, default 0)				
		nentary data value to be encoded into the token. The ation of this value is subclass-specific; refer to IEC 62055-41.				
Format: A decimal integer; the range is subclass-specific.  messageId (optional, default empty) As for Vend Credit Token.						
Output	The output will include the following fields:					
	• idR	ecord As for Vend Credit Token.				
	• sub	class As for input.				
	• des	<b>cription</b> A human-readable description of the to	oken type.			
	• ven	dTimeUnix As for Vend Credit Token.				
<ul> <li>unitsActual The actual number of transfer units issued, as a definteger.</li> <li>unitName The name of the transfer unit for the subclass, printable ASCII string (e.g. subclass 0 units are 100Wh so unit is "hWh").</li> <li>tokenDec The generated token as 20 decimal digits, suitable printing on a POS slip for entry into a meter via a keypad.</li> <li>tokenHex The generated token as 17 hexadecimal charasuitable for transfer to a magnetic token carrier.</li> </ul>						

# **4.5 Query Transaction Counter**

Returns the number of transactions left in the module.

URL	http://host/stsvend/QueryTx.format					
Formats	tsv, ini <i>(default)</i> , xml					
HTTP method(s)	GET					
Input Parameters (Required)	None					
Status codes	200, 400, 405, 415, 500, 503					
Output	txCredit (required)					
	The quantity of transactions still available on the module. Given as a positive integer.					

# Example of use #1 - XML response

#### Request

curl http://localhost:5081/stsvend/QueryTx.xml

#### Response

<?xml version='1.0' encoding='ISO-8859-1'?>
<response>

<txCredit>10000</priceExact>

</response>

### Example of use #2 - TSV response

#### Request

curl http://localhost:5081/stsvend/QueryTx.tsv

#### Response

txCredit 10000

# Example of use #3 – INI response (format not specified)

#### Request

curl http://localhost:5081/stsvend/QueryTx

#### Response

txCredit=10000

# **4.6 Calculate Watt-Hours (LEGACY)**

Computes the quantity of electricity (hundred-Watt hours) that may be purchased for a given price.

URL	http://host/stsvend/CalcWh.format				
Formats	tsv, ini <i>(default)</i> , xml				
HTTP method(s)	POST				
Input	price (required)				
Parameters (Required)	The price that a customer will pay for the token, as a floating-point value in a standard currency unit (e.g. Rands). The decimal separator is a period (.).				
	For example, "1.50" indicates one Rand and fifty cents.				
	Tariff (required)				
	The price for one unit of electricity (100 Watt-hours), as a floating-point value in the same currency unit and format as <b>price</b> .				
	For example, "1.10" indicates one Rand and ten cents per hundred-Watthour.				
	vendorFee (required)				
	A per-vend fee that is charged by the vendor, to be subtracted from the price before applying the tariff. Given as a floating-point value in the same currency unit and format as <b>price</b> .				
	For example, "0.75" indicates a fee of 75 cents.				
Status codes	200, 400, 402, 405, 415, 500, 503				
Output	hwh (required)				
	The quantity of electrical units (hundred-Watt-hours) that may be purchased for the given price, tariff and fee. Given as a positive integer.				
	priceExact (required)				
	The exact price that should be paid for the quantity of electrical units indicated by <b>hwh</b> . <b>PriceExact</b> will always be less than or equal to <b>price</b> , and is given in the same currency unit and format as <b>price</b> .				
	Since vending must occur in discrete units, each costing the amount given by <b>tariff</b> , the input <b>price</b> will seldom correspond exactly to a whole <b>hwh</b> quantity; that is, there will be a rounding error.				
	priceCeil (optional)				
	If <b>priceExact</b> is not equal to <b>price</b> , then <b>priceCeil</b> will indicate the price for ( <b>hwh</b> + 1) electrical units; that is, the ceiling value with respect to the <b>tariff</b> .				

### Example of use #1 - XML response

#### Request

curl http://localhost:5081/stsvend/CalcWh.xml -d price=100 -d tariff=2 -d vendorFee=0

#### Response

```
<?xml version='1.0' encoding='ISO-8859-1'?>
<response>
    <priceExact>100.00</priceExact>
         <hwh>>500</hwh>
         <priceCeil>100.00</priceCeil>
</response>
```

### Example of use #2 - TSV response

#### Request

```
curl http://localhost:5081/stsvend/CalcWh.tsv -d price=1000 -d tariff=1 -d
vendorFee=0.5
```

#### Response

priceExact 10000.00 hwh 99995 priceCeil 10000.00

# Example of use #3 – INI response (format not specified)

#### Request

curl http://localhost:5081/stsvend/CalcWh -d price=45.5 -d tariff=1 -d vendorFee=0.75

#### Response

```
priceExact=45.45
hwh=447
priceCeil=45.55
```

### **Integration Guide**

In this section we provide recommendations on how to use the services of the <u>StsVend API</u> (section 4), and examples for some common use cases.



Each example develops an API concept; we urge you to <u>read all examples</u>, even those that may not seem relevant to your metering requirements.



STS tokens are <u>not predictable</u>: each token contains both time-variant and random data, and TsmWeb-STS detects and prevents duplicate tokens (as required by the STS standard).

Our examples include generated tokens, but you <u>should not</u> expect to see the same token values if you execute the example.

#### Recommended services

If you need to create Electricity, Water, Gas, Time, or Currency credit tokens for a given currency value then you should use the <u>Vend Credit Token</u> service (section 4.3). This service uses the TsmWeb-STS tariff tables (configured though the Web UI) to convert the currency value into appropriate metering units.

If you need to create Electricity credit tokens for a given Watt-hour value then you should use the Query Transaction Counter

Returns the number of transactions left in the module.

URL	http://host/stsvend/QueryTx.format					
Formats	tsv, ini <i>(default)</i> , xml					
HTTP method(s)	GET					
Input Parameters (Required)	None					
Status codes	200, 400, 405, 415, 500, 503					
Output	txCredit (required)					
	The quantity of transactions still available on the module. Given as a positive integer.					

#### Example of use #1 - XML response

#### Request

curl http://localhost:5081/stsvend/QueryTx.xml

#### Response

<?xml version='1.0' encoding='ISO-8859-1'?>

<response>

<txCredit>10000</priceExact>

</response>

#### Example of use #2 - TSV response

#### Request

curl http://localhost:5081/stsvend/QueryTx.tsv

#### Response

txCredit 10000

#### Example of use #3 - INI response (format not specified)

#### Request

curl http://localhost:5081/stsvend/QueryTx

#### Response

txCredit=10000

service (section 4.5). There is no equivalent support for Water, Gas, or Time tokens.

If you need to create Meter-Specific Engineering (MSE) tokens you should use the <u>Vend Meter-Specific Engineering Token</u> service (section 4.4).

You should avoid using the following deprecated services:

- Calculate Watt-Hours (LEGACY)
- Error! Reference source not found.
- Error! Reference source not found.

# 4.7 Special warnings



The TsmWeb-STS Vending UI and the Web API behave slightly differently.

If you are getting different results from the UI and the Web API you should check the following:

- The UI deducts transaction fees from the currency value before creating the token; the Web API does not. Check the transaction fees on the STS Administration page →Fees And Preferences (fields Prism Transaction Fee and Vendor Transaction Fee).
- The UI accepts a currency value in currency units (e.g. Rands, Dollars). The <u>Vend Credit Token</u> service accepts a currency value in <sup>1</sup>/<sub>100</sub> currency units (i.e. "cents"). So if you entered \$50.00 on the UI, you must use value=5000 when calling the service.

### 4.8 Integration setup

The examples in this guide use the Compliance Test Specification (CTS) Test Keys. CTS is the standard used to test & certify STS vending systems.

To work with these examples without modification you will need a Security Module (SM) coded with the CTS MEK and KEK, and a Key Load File (KLF) containing the CTS Test Keys. You can get all of these from Prism.



If you prefer to use real meters and an SM coded with live keys (obtained in a KLF from a KMC) then you will need to replace the SGC and meter identification in the following examples with the values for your Supply Group and Meters.

We use the following Vending Keys (from the CTS KLF):

SGC	KRN	Туре
123456	1	VUDK (Unique key per meter)

We use the following Meters (this table shows identification & configuration):

DRN	SGC	KRN	TI	EA	тст	Type (Subclass)	IDRecord
0000000000	123456	1	01	07	02	Electricity (0)	600727000000000000900000207123456011
01316700887	123456	1	01	07	02	Water (1)	60072701316700887100000207123456011
0315000000002	123456	1	01	07	02	Electricity/ Currency (4)	00000315000000002600000207123456011

We use the following Tariff Tables (you must set up these tables in the TsmWeb-STS UI):

SGC	TI	Subclass (Type)	Rate
123456	01	0 (Electricity)	\$1.24 / kWh
123456	01	1 (Water)	\$1.50 / kL



The tariff table is expressed in local currency units. Credit vends must be denominated in the same units. We use the symbol '\$' to indicate local currency, not a specific national currency.



Transaction fees will be deducted from currency values when vending through the TsmWeb-STS UI, but <u>not</u> when using the Web API's <u>Vend Credit Token</u> method (which is specified as using a value net of fees).

# 4.9 Electricity Credit Token, \$50, Blind Vend

In this example we generate a credit token for an Electricity meter, with a credit value equivalent to 50 currency units (5000 "cents").

The meter is identified by a full 35-digit IDRecord (a "blind vend"). An IDRecord contains the meter's identification (the "MeterPAN") as well as the meter's configuration (SGC, KRN, TI, EA, and TCT). All this information is required by the vending system in order to create a token for the meter.

To generate this token the vending system will use the Vending Key for the meter's SGC and KRN. *In this example SGC=123456 and KRN=1*.

The vending system's Tariff Tables are used to convert the currency value (\$50) into resource units understood by the meter (electricity meters only accept tokens with 100 Watt-hour units). The meter's SGC, TI, and type (subclass) are used to identify the relevant Tariff Table. In this example the meter has SGC=123456, TI=01, and subclass=0, so the Tariff Table gives a rate of \$1.24 / kWh, which translates to a 404 × 100Wh credit token.



Note that the API requires the 'value' input to be in  $^{1}/_{100}$  currency units ("cents"), so for a value of \$50.00 we must use value=5000.

#### Example of use - XML response

#### Request

#### Response

The meanings of the response fields are described in the <u>Vend Credit Token</u> service (section 4.3). STS tokens are not predictable; you will get a different token each time to try this call.

# 4.10 Electricity Credit Token, \$100, MSNO Vend

In this example we generate a credit token for an Electricity meter, with a credit value equivalent to 100 currency units.

The meter is identified by a DRN (a "meter serial number only (MSNO) vend"). The DRN is a shortened form of the MeterPAN (18 digits) that omits the IIN (the prefix "600727" or "0000") and the trailing PANCheckDigit. A DRN is thus 11 or 13 digits.

For an MSNO vend to work the vending system must know the meter's configuration (SGC, KRN, TI, EA, and TCT). The configuration may be known via a previous blind vend (e.g. the use case in section 0), or by entering the meter's configuration on the TsmWeb-STS UI.

As before the vending system must know the Vending Key (for SGC=123456 and KRN=1) and will use the Tariff Table (for SGC=123456, TI=01, and subclass=0) to convert the currency value into resource units for the meter.

#### Example of use - XML response

#### Request

#### Response

<?xml version='1.0' encoding='utf-8'?>

The meanings of the response fields are described in the <u>Vend Credit Token</u> service (section 4.3). STS tokens are not predictable; you will get a different token each time to try this call.

## 4.11 Water Credit Token, \$70, Blind Vend

In this example we generate a credit token for a Water meter, with a credit value equivalent to 70 currency units.

This example uses a different type of meter (Water) and thus a different Tariff Table (for SGC=123456, TI=01, and subclass=1) that translates from currency value in water resource units (100L). The Tariff Table gives a rate of \$1.50 / kL, which translates to a 467 × 100L credit token.

The meter is identified by a full 35-digit IDRecord (a "blind vend"), and the vending system must know the Vending Key (for SGC=123456 and KRN=1).

#### Example of use - XML response

#### Request

```
curl http://localhost:8080/stsvend/VendCredit.xml -d subclass=1 -d meterId=60072701316700887100000207123456011 -d value=7000
```

#### Response

```
<?xml version='1.0' encoding='utf-8'?>
<response><idRecord>60072701316700887100000207123456011</idRecord>
<tariff>15.0</tariff>
<subclass>1</subclass>
<description>Sale - Credit:Water</description>
<vendTimeUnix>1458132780</vendTimeUnix>
<unitsActual>467</unitsActual>
<unitName>hL</unitName>
<valueActual>7005.00</valueActual>
<tokenHex>3A9EC8DE22765BD9F</tokenHex>
<tokenDec>67584549710505295263</tokenDec>
</response>
```

The meanings of the response fields are described in the <u>Vend Credit Token</u> service (section 4.3). STS tokens are not predictable; you will get a different token each time to try this call.

# 4.12 Currency (Electricity) Credit Token, \$120, Blind Vend

In this example we generate a 120 currency unit credit token for a Currency meter that dispenses Electricity.

An Electricity/Currency meter dispenses electricity but accepts credit tokens giving a Currency value rather than a resource unit value. To do this the meter has its own tariff table. The vending system's Tariff Tables are not used in this transaction; instead the currency value (\$120) is encoded into the STS token.

The meter is identified by a full 35-digit IDRecord (a "blind vend"), and the vending system must know the Vending Key (for SGC=123456 and KRN=1).

#### Example of use - XML response

#### Request

```
curl -i http://localhost:8080/stsvend/VendCredit.xml -d subclass=4 -d
meterId=00000315000000002600000207123456011 -d value=12000
```

#### Response

```
HTTP/1.1 200 OK
Date: Wed, 16 Mar 2016 13:59:53 GMT
Server: Prism WSHOST
set-cookie: nsssession=56e966d9.QlKNgocWYUPKveWE00TH_w; Path=/
content-length: 439
content-type: text/xml; charset=utf-8
cache-control: no-store, no-cache, must-revalidate, max-age=0, post-check=0, pre-
expires: Sun, 01 Jul 2005 00:00:00 GMT
pragma: no-cache
vary: Accept-Encoding
<?xml version='1.0' encoding='utf-8'?>
<response><idRecord>00000315000000002600000207123456011</idRecord>
<tariff>1000</tariff>
<subclass>4</subclass>
<description>Sale - Credit:CurrencyElec</description>
<vendTimeUnix>1458136740/vendTimeUnix>
<unitsActual>12.00024</unitsActual>
<unitName>currency</unitName>
<valueActual>12000.24</valueActual>
<tokenHex>17F1A301544549985</tokenHex>
<tokenDec>27605429733819718021</tokenDec>
</response>
```

The meanings of the response fields are described in the <u>Vend Credit Token</u> service (section 4.3). STS tokens are not predictable; you will get a different token each time to try this call.

# 4.13 Currency (Electricity) Credit Token, Replay prevention

In this example we generate a 60 currency unit credit token for a Currency meter that dispenses Electricity, and we include the (optional) 'messageld' field in the request.

The 'messageld' is a unique transaction identifier that is used to detect and prevent replay of the transaction. If you have attempted a transaction but not received a response (for example there may be a timeout or a network interruption) then you cannot be sure whether the transaction was processed or not. In such a case you should resubmit the transaction with the same 'messageld'

The 'messageld' is also useful to identify the origin of the transaction. Refer to <u>Vend Credit</u> <u>Token</u> (section 4.3) for recommended construction of this identifier.

Replay previous (using 'messageld') applies to all services, not just <u>Vend Credit Token</u>. We strongly recommend using it.

The meter is identified by a DRN. The vending system must know the meter's configuration (SGC, KRN, TI, EA, and TCT; e.g. from use case 4.12) and the Vending Key required by that configuration (SGC, KRN). No Tariff Tables are required.

#### Example of use - XML response

#### Request

```
curl -i http://localhost:8080/stsvend/VendCredit.xml -d subclass=4 -d
meterId=000003150000000026000000207123456011 -d value=12000 -d messageId=POS.23.4-
emp0139-20130818T154023Z
```

#### Response

```
HTTP/1.1 200 OK
Date: Wed, 16 Mar 2016 14:02:16 GMT
Server: Prism WSHOST
set-cookie: nsssession=56e96768.BUrRRLOomdLq XowR0i2jg; Path=/
content-length: 439
content-type: text/xml; charset=utf-8
cache-control: no-store, no-cache, must-revalidate, max-age=0, post-check=0, pre-
expires: Sun, 01 Jul 2005 00:00:00 GMT
pragma: no-cache
vary: Accept-Encoding
<?xml version='1.0' encoding='utf-8'?>
<response><idRecord>00000315000000002600000207123456011</idRecord>
<tariff>1000</tariff>
<subclass>4</subclass>
<description>Sale - Credit:CurrencyElec</description>
<vendTimeUnix>1458137040/vendTimeUnix>
<unitsActual>12.00024</unitsActual>
<unitName>currency</unitName>
<valueActual>12000.24</valueActual>
<tokenHex>0069D557A4050FE50</tokenHex>
<tokenDec>00476631119124561488</tokenDec>
</response>
```

The meanings of the response fields are described in the <u>Vend Credit Token</u> service (section 4.3). STS tokens are not predictable; you will get a different token each time to try this call.

# 4.14 Replayed transaction is rejected

In this example we repeat the API call from the previous example (section 4.13) <u>using the same messageld</u>, simulating a replay scenario.

#### Example of use - XML response

#### Request

```
curl -i http://localhost:8080/stsvend/VendCredit.xml -d subclass=4 -d
meterId=00000315000000002600000207123456011 -d value=12000 -d messageId=POS.23.4-
emp0139-20130818T154023Z
```

#### Response

```
HTTP/1.1 500 Internal Server Error
Date: Wed, 16 Mar 2016 14:03:10 GMT
Server: Prism WSHOST
set-cookie: nsssession=56e9679d.kJHcF2sBw 31asIHE4bXqg; Path=/
content-length: 353
content-type: text/html; charset=utf-8
cache-control: no-store, no-cache, must-revalidate, max-age=0, post-check=0, pre-
check=0
expires: Sun, 01 Jul 2005 00:00:00 GMT
pragma: no-cache
vary: Accept-Encoding
                     PUBLIC "-//W3C//DTD HTML 4.01
<!DOCTYPE
            HTML
                                                                 Transitional//EN"
"http://www.w3.org/TR/html4/loose.dtd">
<ht.ml>
<head>
<title>Internal Server Error</title>
</head>
<body>
<h1>Internal Server Error</h1>
Vend credit operation failed. 'Message ID not unique: SQL query failed: UNIQUE
constraint failed: t commits cdu.commitRef'
</body>
</html>
```

# 4.15 Clear Credit Management Token, MSNO Vend

The <u>Vend Meter-Specific Engineering Token</u> service (section 4.4) is used to generate all management tokens.

In this example we create a "Clear Credit" management token. The token function ("Clear Credit") is identified by subclass=1. For this function the 'supp' field is a bitmap indicating which credit registers to clear; we will use supp=65535 to clear all credit registers.

The meter is identified by a DRN (making this an "MSNO vend"). As with calls to <u>Vend Credit Token</u> we could have identified the meter by a full IDRecord (a "blind vend"). Since we identify the meter by DRN the vending system must know the meter's configuration. In all cases the Vending Key corresponding to the meter's configuration (SGC, KRN) is required to create the token.

#### Example of use - XML response

#### Request

 $\verb|curl http://localhost:8080/stsvend/VendMse -d subclass=1 -d meterId=00000000000 -d supp=65535| \\$ 

#### Response

The meanings of the response fields are described in the <u>Vend Meter-Specific Engineering Token</u> service (section 4.4). STS tokens are not predictable; you will get a different token each time to try this call.

# 4.16 Query Meter Information

This endpoint allows the user to do a lookup on a specific meter number, which returns the meters configuration as well as the tariff and channel fee. This is done by appending the meter number to the URL

http://host/stsvend/Meter/drnOrPan.format
tsv (default), ini, xml
GET
drnOrPan is appended as an URLsuffix
200, 400,404,500

#### Output

The output will include the following fields:

- meterPan As for Vend Credit Token.
- sgc The supply group
- krn The key revision number
- **ti** The tariff index
- ea The encryption algorithm (default=07)
- **tct** The token carrier technology (default=02)
- **idRecord** 35 digit IDRecord per IEC 62055-41 (contains MeterPAN, DOE, TCT, EA, SGC, TI, KRN).
- doe The date of expiry.4 digits giving MMYY(?) or "0000". Default "0000"
- **docld** is a string of up to 40 chars that uniquely identifies this Meter Record *and revision*. In order to prevent concurrent modification. Currently unused.
- Drn 11 or 13 ASCII digits representing the meter number
- **isSeen** Y=true or N=false. Whether PrismVend has issued tokens to the meter before. A meter can be seen (i.e blind vending) but not registered on the system
- **isRegistered** Y=true or N=false. Whether PrismVend has the meter information stored and the operator has indicated that the meter information is the current correct information
- **resType** Resource type or subclass. Integer 0-7. e.g. 0=Electricity,1=Water
- name String which appears as the name on the token slip which allows the operator to categorize or group meters that are searchable.
   Only displayed on the token with a "customize" licence applied in the Licence Manager
- organisation String which appears as the organisation on the token slip which allows the operator to categorize or group meters that are searchable. Only displayed on the token with a "customize" licence applied in the Licence Manager
- channelFee String, Sum of Prism Fee and Vendor Fee, formatted for human reader, with currency symbol, e.g. R0.78 or 0.78 R or 0.78 ZAR
- tariffRate String, applicable tariff for SGC/ResType/TI formatted for human reader, with currency symbol and resource symbol, e.g. R1.62/kWh or 1.62 R/kWh or 1.62 ZAR/kWh

#### Example of use #1 – XML response

#### Request

curl http://localhost:8080/stsvend/Meter/24140081456.xml

#### Response

```
<?xml version='1.0' encoding='utf-8'?>
<response><meterPan>600727241400814561</meterPan>
<sgc>400008</sgc>
<krn>1</krn>
<ti>1</ti>
<ea>7</ea>
<tct>2</tct>
<idRecord>60072724140081456100000207400008011</idRecord>
<doe>0000</doe>
<docId>600727241400814561;268</docId>
<drn>24140081456</drn>
<isSeen>1</isSeen>
<isRegistered>1</isRegistered>
<resType>0</resType>
<name>Alice</name>
<organisation>ACNOPE</organisation>
<channelFee>R0.25</channelFee>
<tariffRate>R2.1100</tariffRate>
</response>
```

### Example of use #2 - INI response (with HTTP headers shown)

#### Request

```
curl -i http://localhost:8080/stsvend/Meter/24140081456.xml
HTTP/1.1 200 OK
Date: Thu, 25 Nov 2021 10:17:26 GMT
Server: Prism WSHOST
set-cookie: nsshttp=619f62b6.5b-4JYuRcyjD1EUdSgvCUg; Path=/; HttpOnly
cache-control: no-store, no-cache, must-revalidate, max-age=0, post-check=0, pre-
check=0
expires: Sun, 01 Jul 2005 00:00:00 GMT
pragma: no-cache
content-type: text/xml; charset=utf-8
X-Frame-Options: sameorigin
X-XSS-Protection: 1; mode=block
X-Content-Type-Options: nosniff
Content-Security-Policy: default-src 'self' 'unsafe-inline' 'unsafe-eval'; connect-src
content-length: 490
vary: Accept-Encoding
```

```
<?xml version='1.0' encoding='utf-8'?>
<response><meterPan>600727241400814561</meterPan>
<sgc>400008</sgc>
<krn>1</krn>
<ti>1</ti>
<ea>7</ea>
<tct>2</tct>
<idRecord>60072724140081456100000207400008011</idRecord>
<doe>0000</doe>
<docId>600727241400814561;268</docId>
<drn>24140081456</drn>
<isSeen>1</isSeen>
<isRegistered>1</isRegistered>
<resType>0</resType>
<name>Alice</name>
<organisation>ACNOPE</organisation>
<channelFee>R0.25</channelFee>
<tariffRate>R2.1100</tariffRate>
</response>
```

# **5. Amendment History**

Version	Description	Person	Date
3.9.0	Duplicate of PR-D2-0835 (StsClosedVending API).	TD	2013/03/06
3.29.0	Document adapted from PR-D2-0835 "Prism STS Vending Web Service" (rev 3.9.0).	TD	2013/09/05
	Updated to indicate legacy services, and to document the "Vend Credit" service.		
3.32.0	Added "Vend Meter-Specific Engineering Token" service.	TD	2013/10/24
4.17	Added table of management functions to Vend Meter-Specific Engineering Token.	TD, CA	2016/03/14
	Added the Integration Guide and examples.		
4.17.1	Fixed description of 'idRecord' output field in VendCredit.	TD	2016/04/29
4.23.8	Updated docs for Vend Credit Token, in particular the response fields unitName and valueActual.	TD	2016/07/22
4.27.4	Removed references to outdated readme	CA	2015/09/30
4.27.12	Added new subclass value to the VendCredit API function. If -1 is specified the CDU will perform a database look up to determine the resource type of the registered meter	CA	2017/01/29
4.29	Added a new call \QueryTx, which queries the transaction counter	СМ	2017/02/04
4.35	Changed the description of 'Meter Key Change' under 'Supported Subclasses' to point to the User Interface	СМ	2017/03/23
4.36	Added terms, definitions and abbreviations section	CA	2017/04/28
4.37	Removed all legacy API commands that are either unsupported or have replacement commands.	CA	2017/12/11
4.38	Fixed all curl examples so that they can be copied, pasted and executed in a console.	CA	2018/08/23
4.40	Added /Meter endpoint which allows the user to query a specific meters configuration	CA	2021/11/25